SCULPTED GRACE



hotbath
italian bathroomware

GUY *finishes*



ROW


DIAMOND

METAL PLATED GN
Brushed Nickel

PERMANENT PATINA TB
Tuscan Bronze

VAPOR DEPOSITION BBP
Brushed Brass PVD

VAPOR DEPOSITION MBP
Matt Black PVD







GY003R - GY003D
Washbasin mixer
R D



GY003HR - GY003HD
High washbasin mixer
R D



GY004R - GY004D
Washbasin mixer, with swivel spout
R D



GY023R - GY023D
2-hole washbasin mixer,
with swivel spout
R D



GY023HR - GY023HD
2-hole washbasin mixer,
with high swivel spout
R D



GY005R-20 - GY005D-20
Concealed washbasin mixer,
with spout length 20 cm
R D



GY005R-25 - GY005D-25
Concealed washbasin mixer,
with spout length 25 cm
R D



P708
Washbasin waste, free-flow



P710
Push-button washbasin waste



P035
Washbasin trap



GY018R - GY018D
Bidet mixer
R D



KHDS3
Shut-off mixer, with push-button
hand shower



CBA321
Actuator plate for Geberit Sigma 8 -
Sigma 12, with magnetic fixing



GY031R - GY031D
Concealed shower mixer

R D



GY011R - GY011D
2-way concealed diverter (without closing function)

R D



M317
Sliding rail with flexible hose,
hand shower and wall coupling



GY7009R - GY7009D
Concealed thermostatic mixer,
with 2-way diverter

R D



GY7066R - GY7066D
Concealed thermostatic mixer,
with 2 stop valves

R D



GY7067R - GY7067D
Concealed thermostatic mixer,
with 2 stop valves

R D



GY7070R - GY7070D
Concealed thermostatic mixer, with 3 stop valves

R D



M445
Shower set including wall coupling,
hand shower and flexible hose



GY7071R - GY7071D
Concealed thermomixer, with 2 stop valves and hand shower

R D




M446
Shower set including wall coupling,
hand shower and flexible hose



M318
Sliding rail with flexible hose, ø 9,4 cm
hand shower and wall coupling



AR470
Wall-mounted triple-jet shower head



AR471
Wall-mounted monojet shower head
(SoftJet)



AR472
Ceiling-mounted monojet shower head
(SoftJet)



CB450 + M100
Wall-mounted shower arm
+ head ø 20 cm



CB450 + M105
Wall-mounted shower arm
+ head ø 25 cm



CB450 + M106
Wall-mounted shower arm
+ head ø 30 cm



CB452 + M100
Ceiling-mounted shower arm
+ head ø 20 cm



CB452 + M105
Ceiling-mounted shower arm
+ head ø 25 cm



CB452 + M106
Ceiling-mounted shower arm
+ head ø 30 cm



GUY

BATHTUB



GY177R - GY177D
Floor-standing bathtub mixer, with flexible hose and hand shower

R D



GY073R - GY073D
Deck-mounted set for bathtub, with 2 mixers, spout and hand shower

R D



GY075R - GY075D
Deck-mounted set for bathtub, with 2 mixers and hand shower

R D



GY176
Floor-standing spout for bathtub

R D



GY7072R - GY7072D
Thermomixer for bathtub, with 2 stop valves, spout and hand shower

R D



P032
Bathtub pop-up waste, with overflow



P033
Bathtub pop-up waste with spout, with overflow



CBA01
Wall-mounted tumbler holder



CBA02
Wall-mounted soap holder



CBA04
Paper holder



CBA05
Double paper holder



CBA06
Towel holder, 34 cm



CBA07
Towel holder, 64 cm



CBA08
Ring towel holder



CBA03
Robe hook



CBA09
Wall-mounted soap dispenser



CBA10
Free-standing soap dispenser



CBA11
Wall-mounted toilet brush holder



CBA12
Free-standing toilet brush holder



CBA20
Wall-mounted magnifying mirror



CBA22
Corner shelf